

safety

- **Do not use the juicer if the filter is damaged.**
- Never put the motor unit, cord or plug in water – you could get an electric shock.
- Switch off and unplug:
 - before fitting or removing parts
 - before cleaning
 - after use.
- Never use a damaged juicer. Get it checked or repaired: see 'Service and customer care', page 6.
- Only use the pusher supplied. Never put your fingers in the feed tube. Unplug before unblocking the feed tube.
- Before removing the lid, switch off and wait for the filter to stop.
- Don't let children or infirm people use the juicer without supervision.
- Never let the cord touch hot surfaces or hang down where a child could grab it.
- Don't touch moving parts.
- Never leave the juicer on unattended.
- This juicer is for domestic use only.
- Don't let children play with the machine.

before plugging in



- Make sure your electricity supply is the same as the one shown on the underside of your juicer.
- Important (UK only)
- The wires in the cord are coloured as follows:
Blue = Neutral, Brown = Live.
 - This juicer complies with European Economic Community Directive 89/336/EEC.

before using for the first time

- 1 Remove all packaging.
- 2 To take your juicer apart: see 'To take your juicer apart', page 5.
- 3 Wash the parts: see 'Cleaning', page 5.

know your Kenwood centrifugal juicer

- ① pusher
- ② hopper
- ③ lid
- ④ filter
- ⑤ pulp collector
- ⑥ lid with foam separator
- ⑦ juice jug
- ⑧ speed control
- ⑨ motor unit
- ⑩ interlock
- ⑪ compartment for excess cord




to assemble and use your juicer

preparing food

- Remove stones (plums, peaches, cherries etc).
- Remove tough skins (melons, pineapples, cucumbers, potatoes etc).
- Soft-skinned and other foods just need washing (apples, pears, carrots, radishes, lettuce, cabbage, parsley, spinach, grapes, strawberries, celery etc).
- Citrus Fruit - Peel and remove the white pith, otherwise the juice may taste bitter. For best results Kenwood citrus juicers are recommended for citrus fruit.

assembly and use

- 1 Fit the pulp collector **1**.
 - 2 Fit the filter inside the pulp collector **2**.
 - 3 Put the lid on and push down firmly on the feed tube. Then slide the interlock switch **3** to lock the lid. **Your juicer will not work if the lid is unlocked.**
 - 4 Place the hopper onto the lid **4**.
 - 5 Push any excess cord into the compartment at the back of the juicer.
 - 6 Put the juice jug under the outlet **5**. The foam separator in the jug ensures that the juice is free from foam **6**.
 - 7 Cut the food into small pieces to fit the feed tube.
 - 8 Switch on **7** and push down with the pusher. Use speed 1 for softer food; speed 2 for harder foods.
- Some very hard foods may make your juicer slow down or stop. If this happens switch off and unblock the filter.
 - Switch off and clear the pulp collector regularly during use.
- Always unplug after use.**



hints

- Insert soft food slowly to get the most juice.
- Vitamins disappear - the sooner you drink your juice, the more vitamins you'll get.
- If you need to store the juice for a few hours put it in the fridge. It will keep better if you add a few drops of lemon juice.
- Don't drink more than three 230mls (8 fl.oz.) glasses of juice a day unless you're used to it.
- Dilute juice for children with an equal amount of water.
- Juice from dark green (broccoli, spinach etc) or dark red (beetroot, red cabbage etc) vegetables is extremely strong, so always dilute it.
- Fruit juice is high in Fructose (fruit sugar), so people with diabetes or low blood sugar should avoid drinking too much.
- Don't mix fruit and vegetable juice together (apart from apple and carrot) - it can cause painful wind or bloating.

to take your juicer apart

- 1 Unplug.
- 2 Lift out the pusher ① and remove the hopper ②.
- 3 Release the lid by sliding the interlock switch back ③. Lift off the lid.
- 4 Lift out the filter ④.
- 5 Lift out the pulp collector ⑤.
- 6 Remove the juice jug.

cleaning

- Before cleaning, unplug your juicer.
- If the filter is too tight to remove, wait a few minutes until it loosens up.
- We don't recommend washing any of the parts in the dishwasher.
- Some foods, eg carrot, will discolour the plastic. Rubbing with a cloth dipped in vegetable oil helps remove discolouring.


motor unit

- Wipe with a damp cloth, then dry.

pulp collector, lid, pusher, hopper

- Wash, then dry.
- **filter**
- Clean using a soft brush.
- **Check the filter regularly for signs of damage. Do not use if the filter is damaged. Refer to “service and customer care”**

Note: The hopper can be inverted for storage on the juicer ⑥



service and customer care

- If the cord is damaged it must, for safety reasons, be replaced by KENWOOD or an authorised KENWOOD repairer.

UK If you need help with:

- using your juicer or
- servicing or repairs (in or out of guarantee)
- ☎ call Kenwood customer care on **023 9239 2333. Have your model number ready** - it's on the underside of your juicer.
- **spares and attachments**
- ☎ call 0870 2413653.

other countries • Contact the shop where you bought your juicer.

UK only **guarantee**

If your juicer goes wrong within one year from the date you bought it, we will repair or **where necessary** replace it free of charge provided;


- you have not misused, neglected or damaged it;
- it has not been modified (unless by Kenwood);
- it is not second-hand;
- it has not been used commercially;
- you have not fitted a plug incorrectly; and
- **you supply your receipt to show when you bought it.**

This guarantee does not affect your statutory rights.

instructions

Kenwood JE550

With your Kenwood Centrifugal Juicer you can enjoy the delicious, natural taste of the freshest juice - from your own choice of fruit and vegetables. And being a Kenwood, it's easy to use. So enjoy a healthier lifestyle with your Kenwood Centrifugal Juicer.



KENWOOD

Kenwood Limited, New Lane, Havant, Hampshire PO9 2NH, UK

